



SW4, BX=ON

	2414MHz	2432MHz	2450MHz	2468MHz
SW3, CS2	OFF	OFF	ON	OFF
SW2, CS1	OFF	ON	OFF	OFF
SW1, CS0	ON	OFF	OFF	OFF